AFEDRI SDR-USB-HS – short user manual.

1. AFEDRI SDR-USB-HS main information.

The image of AFEDRI SDR-USB-HS receiver, it contains also the external connectors and indication LEDs that are marked on the picture (see **Figure 1.)**. There is short description of marked connectors and indication LEDs.



Figure 1.1 AFEDRI SDR-USB-HS receiver

- **1.1** JP1 connector (RF Input connector) This SMA or BNC type connector, it is used to connect external antenna or any other RF signal source (maximum limit is 13dbm).
- **1.2** J10 connector (USB connector) it is used to connect USB cable (mini-B USB type) between SDR and PC. This connector provides +5VDC power supply for SDR, and control/data stream transfer. Mini-B USB connector pin-out you can see on Figure.2

Contact Number	Signal Name	Typical Wiring Assignment
<u>1</u>	VBUS	Red
2	<u>D-</u>	White
<u>3</u>	<u>D+</u>	Green
<u>4</u>	<u>ID</u>	not connected
<u>5</u>	GND	Black
<u>Shell</u>	<u>Shield</u>	<u>Drain Wire</u>

Table 6-2. USB Series "mini-B" Connector Termination Assignment

Figure 1.2 Mini-B USB connector pinout

- **1.3** Blue LED (blue or green) during data stream transfer is indicating that AFEDRI SDR-USB-HS front-end IC is functioning properly, including all electronics, that is servicing data stream transfer path (CPU). If there is not problem during data stream transfer, so Blue LED has to be blinking (switching On and OFF) consequently, during data transfer only. If Blue LED is not blinking, i.e. LED is constantly lighting (On) or switched OFF during data reception, so there is problem in hardware functioning or in software. In the case of problem you need to "reset" AFEDRI SDR-USB-HS by USB cable disconnection.
- **1.4** Yellow LED (yellow) is used for indication of proper finishing of Front-end IC initialization. The Yellow LED will be slow blinking If front-end was initialized successfully.

Attention!!! You should not start any software that is using AFEDRI SDR-USB-HS (Linrad, SDR-Radio, Winrad, HDSDR, WRPlus), till SDR's firmware will finish start-up initialization, so you need to wait till Yellow will begin to blink!!!

1.5 Red LED (red) – this LED is connected to +5V voltage, that coming from USB line. It is constantly lighting if 5VDC voltage is present.

2 Description of AFEDRI SDR-USB-HS in two alternative USB modes

AFEDRI SDR-USB-HS can be configured to work in two alternative USB modes:

USB Audio device emulation and **USB Mass Storage Device** (**MSD**). User can configure SDR for desired mode using SDR_Network_Control_box utility (HDSDR/Winrad plug-in). Required controls are located on Command shell tab (see **Figure 2.1**). To configure AFEDRI SDR-USB-HS to desired mode, you need to do next:

- Start SDR_Control.exe utility
- Go to "Command shell" tab
- To use SDR in **USB Audio mode** check "USB Audio" check box
- To use SDR in USB Mass Storage device mode uncheck "USB Audio" check box
- Press "Save USB mode" button, to save desired mode

• Reboot SDR - press "Reset SDR" button located on "About" tab or disconnect and connect again USB cable from SDR.

The new USB mode is actual only after SDR reset!

Below you can find the short description of each mode:

2.1 USB Audio emulation mode

In this mode SDR is detected by PC as USB Audio device (Sound Card) and USB HID device

USB Audio interface is used for I/Q data transfer, USB HID for radio control. This mode is similar to USB mode of AFEDRi SDR-Net receivers with some limitations:

- On Windows OS on some PCs the maximal sample rate can be 96kHz only! This depends on used motherboard and windows USB system drivers
- On Linux OS the maximal sample rate can be up to 981333 Hz (you can prefer to use the standard USB Audio values: 48khz, 96kHz, 192kHz, 384kHz, 768kHz)

2.2 USB Mass Storage Device (MSD)

More universal and advanced mode than USB Audio.

In this mode SDR is detected by PC as USB Mass Storage Device (MSD) or other word USB Flash Removable Disk, operational system will detect and install all needed drivers automatically and will invite you to read the new removable disk storage (ignore it, but – remember the disk letter, let say "F:\" or "H:\" – on Windows or /media/removable – on Linux).

You must define this disk letter to SDR_Control (SDR_Network_Control_Box) using "MSD Path" File box located on "Command shell" tab. After you will choose the SDR latter it will be stored by SDR_Control in configuration file (sdr_config.ini).

Operation of AFEDRI SDR-USB-HS in MSD mode make it easier for SDR application writer - because all control and data stream operation are done using standard **unbuffered** File Inputoutput operations .

Check this check box to configure SDR for USB Audio mode Uncheck this check box to configure SDR for MSD mode

DR Control	Command shell	Filter tools	Network	k Multy Cl	hannel RX	About			
Route cons	ole output to HID interj	lace				Audio mode	e	Save sample rate	
Command Input			Frequency compensation Save USB Mode			de	Save Main Clock		
				DAC value				Save VCO voltage	
				128 🛓				Save Gain table	
			1	Gain table				Get Sync State	
				Emulated Gain	RF Gain			Save defaults	
				0dB	17db	÷	Calibration		
MCD Juda				-10dB	14db	A Y	Test signal fr	equency (Hz)	
H:/	e paun		-	-20dB	8db	*	Measured signal frequency (Hz)		
	Choose SDR Path			-30dB	2db	×			
L							Calculate M	fain Clock frequency	

Figure 2.1 USB mode configuration for AFEDRI SDR-USB-HS.

3 AFEDRI SDR-USB-HS firmware upgrade

3.1 Firmware upgrade of AFEDRI SDR-USB-HS receiver can be done using USB connection. At first you should install the Flip 3.4.7 utility that contains all needed drivers and utilities required for firmware upgrade, it can be downloaded from Atmel web site using next link:

http://www.atmel.com/tools/FLIP.aspx

You need to do next sequence for AFEDRI SDR-USB-HS firmware upgrade:

- 3.1.1.Download Flip 3.4.7 utility from Atmel site and install it on your PC
- 3.1.2. Download latest firmware from <u>afedri-sdr.com</u> web site (for example the file afedri-sdr-usb-hs-fw_v2012.zip)
- 3.1.3. Save firmware archive in any folder on your hard Disk and extract files from this archive, you will see the next files that were extracted from archive (see **Figure 3.1**). Where for example you can see next files:
 - afedri_usb_ms.hex it is firmware hex file
 - firmware_upgrade.bat command shell batch file that will run upgrade process
 - start.bat command shell batch file that will help you to cancel firmware upgrade if you decide do not make upgrade.

	ware F arean-sar-usp-ns-rw_v2012	• • sean	ch ujeun-sur-uso-ns-jw_V2012
e Edit View Tools	Help		
Organize 🔻 🛛 Include in I	library 🔻 Share with 💌 New fold	der	
🔆 Favorites	Name	Date modified	Type Size
🧮 Desktop	afedri_usb_ms.hex	09/06/14 12:37 PM	HEX File 11
🐌 Downloads	🚳 firmware_upgrade	03/11/13 4:50 PM	Windows Batch File
📃 Recent Places	🚳 start	07/11/13 12:11 PM	Windows Batch File
词 Libraries			
Documents			
J Music			
Pictures			
Subversion			
Videos			
🍪 Homegroup			
Computer			
🚢 Local Disk (C:)			
👝 Local Disk (D:)			
👝 Local Disk (E:)			
💼 Local Disk (G:)			
🙀 Network			
	1	m	

Figure 3.1 Firmware archive files

3.1.4. You need to switch AFEDRI SDR-USB-HS to firmware upgrade mode using command that sent from "SDR Network Control Box" application. User need to press the button "Firmware Upgrade", that is located on the "About" tab (see Figure 3.1). Alternatively you can boot SDR in Firmware upgrade mode using twizzers and shorting pins 5 and 3 of J7 connector and connecting USB cable to PC when this two pins are shortened (see Figure 3.1.1).

SDR Network	Control Box x4 (v.5.	04)				
SDR Control	Command shell	Filter tools	Network	Multy Channel RX	About	~
Ser Firi HW	ial Number C81C5 nWare Verision: 20 //CPLD version: 00(6CC 01 120001				Firmware upgrade Reset SDR
Fro San Sin	ntEnd Main Clock F 1ple rate: 192000 gle Channel RX moo	requency: 800 le)00000(Hz)			
Sofi	ware Designed by: .	Alexander Tru Igor Maslo (G	shkin, 4Z5L raphical Des	V and ign)		

Figure 3.1 «About» tab, «Firmware Upgrade» button



Figure 3.1.1 Jumper place (short cut by twizzers)

- 3.1.5. When you press "Firmware upgrade" button the SDR will reset and starting in the new firmware-upgrade (DFU) mode, please wait till Operational system will detect the new USB device and install required drivers (required for upgrade process)
- 3.1.6. When Drivers successfully installed you should start DOS shell (Command shell) window (see Figure 3.2)

focus mouse and click button on cmd Program	_
Programs (1) Company: Microsoft Corporation File version: 6.1.7601.17514 Date created: 21/11/10 5:23 AM Date created: 21/11/	(1)
IIIb_na Size: 337 KB Compiler Sd_mmc_protocol Smc Files (11730)	
cmd find find find	(7)
See more results cmd X Shut down	

Figure 3.2 DOS (Command shell) strat.

3.1.7. Go to the folder where firmware archive files are located and run firmware_upgrade.bat command file. Wait till the process finish.

(see Figure 3.3)



Figure 3.3 Firmware upgrade shell window.

4 Recommendations for AFEDRI SDR-Net used with USB connection and Windows 7

If you has changed sample rate of AFEDRI SDR-USB-HS, when it connected by USB line to PC with Windows 7 installed, you can see error massage, that shown on **Figure 4.1**. This message can appears when user is pressing "Start" button of Winrad (HDSDR, WRPlus etc.).



Figure 4.1 USB Audio Device Wave Format error message on Windows 7.

With latest AFEDRI SDR-USB-HS firmware versions this massage shows that HDSDR was configured to use "AFEDRI SDR-Net audio Line input" as input Sound card or/and you did not install the SDR_Control box dll as plugin for HDSDR!!! To install SDR_Control box as HDSDR plug-in you should:

- Exit HDSDR
- copy all files from SDR_Network_Control_Box directory to folder where HDSDR installed (for example to C:\Program Files\HDSDR).
- Restart HDSDR application.

When SDR_Control is installed as plug-in it should be started automatically when users starts HDSDR application, you should not start is manually!

If you see System error message "Unspecified Sound error code 1", when pressing "Start" button, this error appearing when USB port where you connect the SDR is not able provide the sample rate that SDR configured (192kHz by default). (See. **Figure 4.2.**)



Figure 4.2 "Control Panel" -> "Hardware and Sound" window

This problem can be solved using one of two ways:

- Try to connect SDR to alternative USB port
- Try to decrease AFEDRI SDR-net USB sample rate to lower value (you can try 96000 Hz or 48000 Hz).

The USB sample rate value can be changed using next sequence (See. Figure 4.2):

- Run SDR_Control utility
- Switch to "Command shell" tab
- Input the new sample rate value in "Command Input" edit box.
- Press "Save sample rate" button
- To make the new value actual for OS, restart SDR, pressing "Reset SDR" button that located on "About" tab or disconnect USB cable from PC and connect it again.

SDR Network	Control Box x2 (v.4	15)						
SDR Control	Command shell	Filter tools	Network	Dual Cham	nel RX	About		
Route controls output to HID interface Command Input 192000 Input here desired value in Hertz			Frequency compensation DAC value 128 牵 Gain table Emulated Gain	Pr sa RF Gain	ess thi ve nev	is button to v sample i	, Save sample rate Save Main Clock rate Save VCO voltage Save Gain table Get Sync State	
			0dB -10dB -20dB -30dB	11d 8d 2d -4d	b v b v b v b v	Calibration Test signal fre Measured sign	equency (Hz) nal frequency (Hz)	
	Save defaults						Calculate M	fain Clock frequency

Figure 4.3 USB audio sample rate configuration

4.1.1 Sample rate configuration in USB Mass Storage device (MSD) mode

In USB Mass Storage Device (MSD) mode the sample rate of receiver can be changed on "Network" tab, You need to insert desired value in Hertz units and press "Enter" key to change it.

In MSD mode you can change the sample rate value non-stopping reception process (in real time). See **Figure 4.4**

	Command shell	Filter tools	Network	Multy Channel RX	About	
	SDR IPAddress		Disable D	UCD Camer	Destination IP Add	lress
	0.0.0.0 SDR IP Mask 0.0.0.0				0.0.0	
			Emulatio	n ID	Destination Por	t
			Save As De	efault ID		
	Gateway IPAddress	. (Multi Stre	am	Enable Netwo	ork Interface
	0.0.0.0		Off	<u> </u>		
	Edit Network Para	meters rameters	Save Mult	i Stream		
	Sample rate (sam	ples/s)		Ne	twork Sample Rate	
		Π		9	81333	1000000
	1			1	Start UDP Stream Broadcast UDP Stream	12
	UDP Packets erro	 []			Broadcast Slava	

Figure 4.4 Where to change the MSD sample rate.

Enjoy! 73!